



ENTERING SEED BLENDS INTO A DAILY SOURCE REPORT

Navigation

Materials > Daily Source Reports

Test Case Steps

1. Click on the **Component Action** button and select **Add**
2. Enter part of the source name in the **Search** field
3. Select the desired Source from the list
4. Select the inspection date from the **Date** calendar popup
5. Check the **Inspector on Site** checkbox if applicable
6. If applicable, select a Remarks **Type** of DSR Inspection and enter comments in the **Remark** field
7. Click **Save**

Source: TREASUR - Treasure State Seed Company Facility: - Date: 10/29/2018

General	Source *	Remarks
Materials	<input type="text" value="TREASUR"/> Treasure State Seed Company	1
Inspection	Facility <input type="text" value="Begin typing to search or press Enter"/>	Inspector JamesK
	Date * <input type="text" value="10/29/2018"/>	Locked By
	Inspector on Site <input checked="" type="checkbox"/>	Locked Date
	Remarks	
	Type * <input type="text" value="DSRInsp - DSR Inspection"/>	Remark * <input type="text" value="Seed ReVeg"/>

8. Click on the **Materials** tab
9. Click the **Select Materials** button
10. Check **713.08.01.01 Seed** row
11. Click the **Add to DSR** button
12. Click **Save**
13. Click the **Row action** button and select **Add New SMFMI**
14. In the **SMFMI Name** field enter the contract followed by a description (i.e. 01718_ReVeg, or 01718_Area3, etc.)
15. Select the current date in the **Effective Date** calendar popup
16. Select **ACTIVE - Active** from the **Status** dropdown list
17. Click **Save**
18. Click on the > to expand the Material section



MONTANA DEPARTMENT OF TRANSPORTATION
AASHTOWare Project CONSTRUCTION and MATERIALS



19. Select *Pre-Inspected Material* from the **Inspection Value** dropdown list
20. Click **Save**

Materials Advanced Showing 1 of 1

Inspection 0 mar

Select Materials...
Expand/Collapse this Panel

Material	English Unit	Metric Unit	SMFMI
713.08.00.01 - Seed	ACRE - Acre	HA - Hectacre	1

SMFMI	Inspection Value	Max Quantity	Effective Date	Expiration Date
01718_ReVeg	PREI - Pre-inspected Material		10/29/2018	

21. Click the **SMFMI Row action** button on the SMFMI and select **MDT Grass Seed** under Views
22. Enter the applicable data. Multiple areas can be added to the same agency view.
 - a. Select the Area No from the dropdown list.
 - b. Enter the Acres
 - c. Click the New button for each row to add. Select the Seed Type, enter the Lot No, Lbs PLS, % Purity, % Germ, Pretest Lab No and Date Tested
23. Click **Save**
24. **Total Lbs PLS, %PLS and Bulk Seed Blended** will auto-calculate after saving.

Area No: 1 Acres: 1.00
Bulk Seeding Rate: 26.4 Total Bulk Seed: 26.4

New 0 added | 0 marked for deletion

Seed Type	Lot No	Lbs PLS (acre)	Total Lbs PLS	% Purity	% Germ	% PLS	Bulk Seed Blended	Pretest Lab No	Date Tested
CRTW - Critana Thickspike Whe...	7KH585-55	10.00	10	96.22	96.00	92.37	10.83	18-4278	05/11/2018
LUPW - Luna Pubescent Wheatg...	97204	10.00	10	96.96	98.00	95.02	10.52	19-0731	09/18/2018
PRS - Pryor Slender WG	7JE563-87A	5.00	5	99.45	99.00	98.46	5.08	18-3743	04/04/2018

Area No: 2 Acres: 2.00
Bulk Seeding Rate: 29.5 Total Bulk Seed: 59

New 0 added | 0 marked for deletion

Seed Type	Lot No	Lbs PLS (acre)	Total Lbs PLS	% Purity	% Germ	% PLS	Bulk Seed Blended	Pretest Lab No	Date Tested
CAW - Canada Wildrye	451J65-74	12.00	24	97.55	97.00	94.62	25.36	18-4267	06/05/2018
LUPW - Luna Pubescent Wheatg...	97202	12.00	24	96.74	99.00	95.77	25.06	19-0871	07/20/2018
PRS - Pryor Slender WG	9LE662-87B	4.00	8	95.89	97.00	93.01	8.6	17-3343	08/24/2018

25. Verify that the **Bulk Seeding Rate and Total Bulk Seed** for each seeding area entered are auto-populated after saving
26. Click on the DSR Material SMFMI quick link at the top to exit the Agency View