



MONTANA

Department of Transportation

February
2025

MDT Civil 3D State Kit -
Adjust Structure Sumps

YOUTUBE VIDEO DOCUMENTATION

TABLE OF CONTENTS

Table of Contents	2
Overview	3
Companion Documentation	3
Using the Command.....	3

OVERVIEW

The purpose of the **Adjust Structure Sumps** command is to adjust sump depth for typical precast structures.

If there is a value for structure sump depth, such as for catch basins, Civil 3D correctly sets the sump elevation, because the elevation is based on a set distance from the flow line of the lowest pipe, but **Civil 3D does not account for pipe wall thickness when connecting to a typical precast structure with a zero sump depth value**. Civil 3D places the structure floor at the invert elevation of the pipe, resulting in the pipe wall lining up **within** the structure floor.

This command will automatically adjust the sump elevation for structures with a zero sump depth value by dropping the structure floor the wall thickness of the pipe creating a spatially accurate 3D pipe network, such as for clash detection.

The **Adjust Structure Sumps** command is developed and provided by WisDOT.

COMPANION DOCUMENTATION

YouTube Video Link: https://youtu.be/uB7S_YDcEdo?si=aaqYZrh7BVLi497j

USING THE COMMAND

1. Type **MDTAdjustSumps** at the command line or press the **Adjust Structure Sumps** ribbon button.
2. **Select Structure(s) [All Individual] <All>**
3. Choose selection option.
 - a. Select **Individual** to manually select structures in model space.
 - b. Select **All** to select all structures in the drawing at once.
4. Command will adjust structure sump elevations automatically.
5. (Optional) Press **<F2>** on keyboard to open the AutoCAD Text Window to see results.